

INSTALLATION GUIDE ENGLISH

code: RWA654GD

Name: RACK cabinet, wall mounted, ready-to-assemble 6U/560x450

RoHS IP20

IM RWA654GD
Edition: 3 from 10.08.2016
Supersedes: 2 from 18.10.2013

EN*

1. Intended use:

The RACK 19" cabinet enables integrating CCTV, AC, I&HAS, RTV, LAN, or other systems in small companies or households. It is intended for devices manufactured in enclosures of the 19" standard. Due to the RACK cabinets, the devices are aesthetically mounted and protected against mechanical damage.

2. Specifications:

SPECIFICATIONS	
Mounting dimensions:	W=19", H=6U
External dimensions:	W=560, H=368, D=450 [mm, +/-2]
Net/gross weight:	14,5 / 16,1 [kg]
Materials:	- RACK mounting rails: cold-rolled steel SPCC 1,5mm RAL 9004 - bolted - front door: 5mm toughened glass / SPCC 1,2mm RAL 9004 - hinged - side panels: cold-rolled steel SPCC 0,8mm RAL 9004 - removable
Static load:	60 kg
Use:	inside, IP20
Notes:	 ventilation holes in the top and bottom panel cable ducts in the top and bottom panel wall-mounting - 4 bolts (not included) lockable front door (2 keys included) ready-to-assemble
Certificates, declarations:	RoHS

3. Structure of the cabinet.



4. Assembling instructions:

The wall mounted, ready-to-assemble RACK cabinet is delivered in 2 separate packages.

4.1) Lay the **bottom panel** of the RACK cabinet (package 1/2).



Fig.1

4.2) Bolt 4 RACK rails (package 2/2) to the bottom panel, as shown in the Fig.2.



Fig.2

4.3) Place the top panel onto the RACK rails and bolt accordingly to the figure below.




Fig.3

4.4) Bolt the lock handle to the front-left RACK rail.



Fig.4

4.5) Mount the front door, rear and side panels - Fig.5



MANUFACTURER

Pulsar Siedlec 150,

32-744 Łapczyca Tel. 14-610-19-40, Fax. 14-610-19-50

e-mail: biuro@pulsar.pl, sales@pulsar.pl http://www.pulsar.pl, www.zasilacze.pl

WARRANTY

12 months from the date of purchase.

THE WARRANTY IS VALID only upon presentation of the item's proof of purchase.